## Kenwood CTOR cables - see next page for Scramble version


DBISHD's show pins at radio end; RJ45's are box ends

J21 is on Scramble Cable page

Dtor & Rtor added to mix TOR and COR (TOR does not send COR in MON)

R244 added to prevent keying if desk power dies! dead +5 in hub loads PTT

These parts on 16x13mm PCB in DBISHD shell





CTM D. 1:				
STM Radio				
Kenwood Cables				
Stan Jones	Rev 2.5	Page 1		
	5/28/2012	rage i		



Scramble cable (radio mod required)

Can be used for tone-activated repeater but not carrier-only repeater






Note Rx audio on pin 9
No COR programmed; TOR not programmed
Radio does squelching, Qsqx not active
Program TOR if tone-operated repeat is
needed, else let radio do all squelching
Radio modified to send audio out
from speaker (1C705 pin 1) to pin 9
through luF, + to IC705
Min volume programmed to "4"

Audio is still present on pin 4 but it will not be unscrambled

STM Radio			
Kenwood Scramble cable			
Stan Jones	Rev 1.0		
	1/26/2016	Page 2	


Send 140 to desks, let them regulate it: line may sag 20




16 pin plug will also fit center pins on CDM models BUT
CDM's CTOR may pull up to only 3.50; if so, prog as active high and add a digital NPN inverter
Inverter and its pull up can be here or in hub (preferably in cable; pull up to B+ pin 13)
To prevent hub-power-off keying radio, connect PTT to B+ with 22k. No series diode needed.


Program Rx Audio to de-emphasised muted
This is also post-descramble
CTOR is not used if no repeater
CTOR may be open collector on some models
If so, add a pullup

STM Radio				
Motorola	Cable,	De	esk	Jacks
Stan Jones	Rev 1.0		Р	age 3
	1/29/2016		l .	-







Outputs have internal diodes to +5, so if power dies in hub, radios lock to 00 channel 4 In case hub dies but radios have power, unplug control cables to the radios and use panel mikes





be external in power cord 50 is lightly loaded, even by latches, so 78L05 OK 50 in desk drives some LED's but L05 still OK If any mounted gooseneck, put preamp in line between desk and mike


STM Radio			
Hub Channel Set, Power Dist			
Rev 1.0	Page 4		
	el Set,		














If the walwart is unplugged hub power connects to the desk side



Without power jack, this is just a line splitter, saves running two wires to hub

But if the wire is over 100 feet likely better to run two wires, as power may sag on one

Or use jack with walwart at desk

STM Radio		
Jack Spl	itter / P	ower tap
	Rev 2	
Stan Jones	12/19/2014	Page 10